## **Ricmotech Phone Cradle for Fanatec Installation Guide**

## **Items Needed:**

- 1. Fanatec ClubSport or CSL wheel base
- 2. Contents of cradle Kit
  - a. Front Bezel
  - b. Back Plate —
  - c. Spacer Plate —
  - d. Three sets of six spacers
  - e. Twelve #6 x 0.25" screws
  - f. Two M6 screws
  - g. Felt pads
- 3. #2 Phillips Screwdriver
- 4. 4mm Hex Wrench









Image shown is for Thrustmaster mount, Fanatec mount is similar.

The assembled cradle should look similar to this. The felt pads should only be used if there is excess gap in the slot as shown in the next step. The pads can be applied wherever needed.



If there is excess gap in the phone slot use the felt pad(s) to push the phone against the front panel. This is especially required when a camera protrudes on the back of the phone.



Place your phone in the cradle and adjust screws and spacers to locate your phone screen centered in the opening.



Mount the cradle to the wheel base with the M6 screws provided. If the screws on the back of the cradle contact the wheel base then you may use the spacer plate behind the back plate to position the cradle away from the base.



Ricmotech is not able to provide support for any app that runs on your phone and connects to a game. We only provide the mounting cradle. There are many apps available for PC and console games and we do not endorse any of them.

## **Need Help?**

If you run into any problems during the installation of the cradle please contact us directly at tech support at (305) 417-9241 or via email at support@ricmotech.com.

Due to constant improvements to our products, the product you receive may vary slightly from the product shown in the illustrations.

Copyright 2018, Ricmotech LLC. ClubSport® is a trademark of the Fanatec® corporation and the terms are used for reference purposes only. Ricmotech and the phone cradle is not affiliated with Fanatec®.