

Heel-Toe Spacer for the Thrustmaster T3PA and T3PA-PRO Pedal Set



The kit includes a spacer block and 4 screws. The short screws are for the T3PA pedals (plastic base), the long screws are for the T3PA-PRO pedals (metal base).



Remove the 2 screws that secure the brake pedal face using a 2.5mm hex wrench.



Place the supplied spacer behind the original wedge spacer and reinstall the pedal face with the appropriate length screws provided using the same 2.5mm hex wrench.

Notice: Ricmotech is not responsible for any damage you may cause to your Thrustmaster pedals during the installation of the spacer.

Need Help?

If you run into any problems during the installation of the adapter, please contact us directly at technical support at (305) 417-9241 or via email at support@ricmotech.com.

Due to constant improvements to our products, the product you receive may vary slightly from the product shown in the illustrations.

Copyright 2018, Ricmotech LLC. Thrustmaster, T3PA and T3PA-PRO are trademarks of the Guillemot corporation and the terms are used for reference purposes only. Ricmotech LLC is not affiliated with the Guillemot.