

**Tactile Sequential Mod Plate
for Thrustmaster TH8RS and TH8A Shifter**

Version 1.5



Part Code
TMSQ

Installation

1. Remove the shifter knob by unscrewing it from the shaft and remove the 4 screws holding the shifter gate using a 2.5mm hex key.



2. Rotate the mechanism as shown so the sequential plate switch is on the right.

3. Position the mod plate aligning the screw holes. Use the 4 longer screws supplied to mount the mod plate.



4. Reinstall the shifter knob into the shaft.

Re-Calibration

The shifter should work without re-calibration, but it is a good idea to re-calibrate. Follow the steps on the Ricmotech Technical website and follow the instructions here: www.ricmotech.com/kb_results.asp?ID=18

Notice: Ricmotech is not responsible for any damage you may cause to your Thrustmaster Shifter during the installation of the adapter. Installation of this adapter may void the original manufacturer's warranty.

Need Help?

If you run into any problems during the installation of the adapter, please contact us directly at technical support at (305) 417-9241 or via email at mail@ricmotech.com.

Due to constant improvements to our products, the product you receive may vary slightly from the product shown in the illustrations.

Copyright 2017, Ricmotech LLC. Thrustmaster, TH8RS and TH8A are trademarks of the Guillemot and the terms are used for reference purposes only. Ricmotech LLC is not affiliated with the Guillemot.

Ricmotech Sim-Racing Equipment
6157 NW 167th Street, Suite F22
Miami Lakes, FL 33015